



## Knauf Readyfix

### Material

#### Fabric

Knauf Readyfix consists of synthetic dispersion as binder and an exactly set-up combination of particle-sized mineral calcium carbonate fillers and suspending agent.

#### Storage

Protect against direct solar radiation and temperatures below 0°C  
Shelf Life: 6 months if stored at a standard temperature of +23°C.

#### Order information

28kg bucket  
5kg bucket

### Fields of Application

Knauf Readyfix is used

- Indoor for wallpaper and coatable skimming of wall and ceiling plasters (gypsum, lime, lime-cement plasters), of concrete surfaces and aer-ated concrete.
- Joint filling of gypsum boards with AK and SK edges together with joint tape by hand.
- As finish on gypsum board joints, already filled with Knauf Uniflott or Knauf Fugenfüller flush with board surface, to create surfaces with sur-face quality level "Q3"
- For skimming of entire gypsum board surface as background for the creat-ing of surface quality level "Q4"
- Knauf Readyfix is not appropriate to fill joints of perforated boards.

### Properties

- Ready to use
- No mixing or setting times
- Pliable consistence
- Easy filling
- Fast drying
- Easy to sand with Knauf Hand Rasp or Rasp with Handle
- Color adjusted to gypsum boards

# Knauf Readyfix

## Application

### Background

The background has to be dry, even, dust-free and clean. Knauf Boards should be applied tightly on a steady sub-construction, clean and with dust-free joints.

Uneven surfaces should be filled with Knauf Readyfix or Knauf Uniflott to create a smooth substrate. Pre-filled areas must be dry and be well adjusted to the board surface.

### Application temperature / climate

Filling and covering of joints should only take place after the boards have been allowed to rest in the given humidity and temperature zones, and no more longitudinal changes can be expected, i.e. expansion or contraction.

In case of mastic asphalt screed, fill in joints after screed has been applied. Do not fill joints at temperatures below +10°C

### Preparation

Stir compound properly, add a little water to make consistence leaner if necessary.

Always use clean tools and vessels.

### Application

Tools: Swiss Trowel / Finishing Trowel. Fill in joints, apply joint tape and treat by pushing it down with spatula. Before applying next layer the previous must be hardened, respectively dry. Fill screw heads as well. For entire surface covering or smoothing of rough surfaces apply Knauf Readyfix with Trowel / Finishing Trowel or with Airless Piston Pump or spray pump (e.g. PFT-Swing) up to 3 mm layer thickness and spread respectively screed sharply on background. Sand with Hand Rasp / Rasp with Handle after drying out. Remove

### Note

Do not mix Knauf Readyfix with other materials. Clean tools and vessel after use with water.

### Application time

Material hardens through drying. Drying time is approx. 24 hours depending on layer thickness, ambient temperature and humidity.

## KNAUF GYPSOPIIA A.B.E.E.

10 Euripidou Str., GR 176 74 Kallithea

Tel.: 0030 210 9310567/9, Fax: 0030 210 9310568, E-mail: [knauf@knauf.gr](mailto:knauf@knauf.gr)

Werk: Stanos, GR 305 00 Amphilochia

Tel.: 0030 26420 29100, Fax: 0030 26420 29112, 29115